




QUICK GUIDE

LEVEL

Controls the amount of boost.

MINI SWITCH

When set to HI-CUT the high frequencies are slightly rolled off.



LED

When lit the effect is engaged.

FOOTSWITCH

Toggle between on/off.
When switched OFF (bypassed) the unit acts as a unity gain Line Driver, capable of driving even very long cables without tonal loss.

INPUT

A high impedance (1M Ω) mono input.
Plug your instrument in here.

9-12VDC

Plug your power supply in here.
9-12VDC @ 50mA with center negative.
Standard 5.5mm x 2.1mm barrel connection.



OUTPUT

A low impedance (50 Ω) mono output.
Connect to the next pedal or your amp.