



# QUICK GUIDE

## TONE

The TONE control is not a traditional tone control, but a High Frequency Damping control.

When set to fully CW the control is not active.

## GAIN

Controls the amount of gain/overdrive.

## LEVEL

Controls the output level of the unit.



## LED

When lit the effect is engaged.

## FOOTSWITCH

Toggle between on/off.

When switched OFF (bypassed) the unit acts as a unity gain Line Driver, capable of driving even very long cables without tonal loss.

## INPUT

A high impedance ( $1M\Omega$ ) mono input.  
Plug your instrument in here.

## 9-12VDC

Plug your power supply in here.  
9-12VDC @ 50mA with center negative.  
Standard 5.5mm x 2.1mm barrel connection.



## OUTPUT

A low impedance ( $50\Omega$ ) mono output.  
Connect to the next pedal or your amp.