



QUICK GUIDE

TONE

The TONE control is not a traditional tone control, but a High Frequency Damping control.

When set to fully CW the control is not active.

GAIN

Controls the amount of gain/overdrive.



LEVEL

Controls the output level of the unit.

LED

When lit the effect is engaged.

FOOTSWITCH

Toggle between on/off.

When switched OFF (bypassed) the unit acts as a unity gain Line Driver, capable of driving even very long cables without tonal loss.

INPUT

A high impedance ($1M\Omega$) mono input. Plug your instrument in here.

OUTPUT

A low impedance (50Ω) mono output. Connect to the next pedal or your amp.



9-12VDC

Plug your power supply in here. 9-12VDC @ 50mA with center negative. Standard 5.5mm x 2.1mm barrel connection.